


Link do produktu: <https://www.specdiag.pl/new-holland-h8040-instrukcje-napraw-schematy-instalacji-service-manual-p-1728.html>



New Holland H8040 - instrukcje napraw + schematy instalacji - SERVICE MANUAL

Cena **250,00 zł**

Opis produktu


Warsztatowe instrukcje napraw wraz ze schematami instalacji.

Instrukcje serwisowe New Holland
H8040

SERVICE MANUALS


Poniższe zdjęcia są przykładowymi zdjęciami z losowych instrukcji napraw, po dokonaniu zakupu klient otrzymuje dokumentację do wybranego przez siebie modelu.

PRIMARY HYDRAULIC POWER SYSTEM - Exploded view




RCPH10TLB005GAM 1

- | | | |
|-------------------------------------|------------------------------|---------------------------------------|
| 1. Hoses swing control | 5. Hydraulic filter | 9. Left stabilizer hoses |
| 2. Backhoe valve | 6. Loader valve | 10. Right stabilizer hoses |
| 3. Left stabilizer load check valve | 7. Pressure to backhoe valve | 11. Right stabilizer load check valve |
| 4. Return to filter | 8. Swing cushion valve | |




7. Remove the charge air cooler hoses and pipes.




RCPH11TLB015AAM 8


8. Cap (seal) all open ports to keep contaminants from entering the system.




RCPH11TLB015AAM 9

9. Remove the lower radiator hose.






5. Make sure the bevelled washers are in place, install the upper and lower king pins. Torque the bolts to **120 N·m (88.5 lb ft)**




RCPH10TLB002ACL 5

6. Grease the bearing cone and install it onto the swivel housing.




RCPH10TLB007ABL 6

7. Use suitable drivers and install new bearing cups and seal into wheel hub.




5. Remove lifting device.



RCPH11TLB102AAM 5


6. Lower loader frame to the floor.



RCPH11TLB103AAM 6

REMOVING THE TORQUE CONVERTER HOUSING AND TORQUE CONVERTER

STEP 1



Drain the oil from the transaxle. The transaxle holds approximately 40 U.S. quarts (38 litres). If equipped with a PTO, drain the oil from the torque converter housing.

STEP 2


If the machine has four wheel drive, do steps 3 through 7.

STEP 3




Loosen and remove the self-locking nuts from the bolts that hold the guard. Do not remove the bolts now.

STEP 4



Use a floor jack to hold and lower the guard.


STEP 5



Remove the bolts and carefully lower the guard.


STEP 6


Carefully tilt the guard and remove the guard from under the machine.




F37605

- | | |
|----------------------------|---|
| 1. Loader bucket | 9. Dipper or telescopic dipper |
| 2. Loader arm | 10. Backhoe bucket |
| 3. Front axle | 11. Backhoe attachment sideshift carriage |
| 4. Fuel tank | 12. Stabilizers |
| 5. Rear axle | 13. Battery box |
| 6. Operator's compartment | 14. Hydraulic oil tank |
| 7. Engine guard | 15. Swing cylinders |
| 8. Backhoe attachment boom | |





Remove the reverse idler shaft assembly.



Remove the by-pass plug, the spring and the ball.



Ensure both synchronizers are in the neutral position then remove the 1st/2nd shift fork screw.



New Holland

TN 55D - TN 55S - TN 65D - TN 65S - TN 70D -
TN 70S - TN 75D - TN 75S

Szukasz instrukcji napraw do maszyny której
nie ma na naszym sklepie?

Zadzwoń lub napisz do nas tel. 696 915 311 lub
530 894 984 lub
motodiagnostyka2010@gmail.com.

Podaj markę i model maszyny do jakiej
instrukcji poszukujesz.