Dane aktualne na dzień: 29-03-2024 06:42

Link do produktu: https://www.specdiag.pl/komatsu-spycharki-bulldozer-dozer-crawler-dozer-wheel-dozer-komatsu-serwisowe-instrukcje-napraw-dtr-p-1500.html



Komatsu Spycharki BULLDOZER - DOZER - CRAWLER DOZER - WHEEL DOZER - Komatsu - Serwisowe instrukcje napraw - DTR

Cena	**850,00 zł**

Opis produktu

Instrukcje napraw, DTR, schematy instalacji do spycharek Komatsu

Komatsu - Spycharki - Dokumentacje warsztatowe - instrukcje napraw - książki serwisowe - Komatsu

BULLDOZER - DOZER - CRAWLER DOZER - WHEEL DOZER

Komatsu - BULLDOZER – DOZER - CRAWLER DOZER - WHEEL DOZER –

Poniżej lista zawartych instrukcji:

100, 125, TD-7, TD-8 -Shop Manual

D20, D21A, D21PL-5, D21P-5 - Serial number 45001 AND UP, 45003 AND UP - Shop Manual

D20A, P, PL, PLL-6, D21A, E, P, PL-6, D20P-6A, D21P-6A, 6B - Serial number 60001 AND UP - Operation & Maintenance Manual

D20A, P, PL-5 - Serial number 45001, 45003 AND UP - Operation & Maintenance Manual

D20A, PL, PLL-7, D21A-7, D20, D21P-7A - Serial number 80060 AND UP, 62664 AND UP, 80228 AND UP - Operation & Maintenance Manual

D20-A-5, D20PL-5, D20P-5, D20PLL-5, D20P-5A - Serial number 50001 AND UP, 50004 AND UP, 50003 AND UP, 50003 AND UP - Operation & Maintenance Manual

D20A-6, D20P-6, D20P-6A, D20PL-6, D20PLL-6, D20S-6, D20Q-6, D21A-6, D21E-6, D21P-6, D21P-6A, D21P-68, D21PL-6, D21S-6, D21S-6A, D21Q-6 - Serial number 60001 AND UP -Shop Manual

D20A-7, D20P, D20PLL-7, D20P-7A, D21A-7, D21P-7A - Serial number 80805, 62729, 80833 AND UP, 80805, 80833-0peration & Maintenance Manual

D20A-7, D20PL-7, D20PLL-7, D20P-7A, D21A-7, D21P-7A - Serial number 78604 AND UP, 62454 AND UP, 78604 AND UP - Operation & Maintenance Manual

D20AG-7, D20PL-7, D20PLL-7, D21A-7, D21AG-7, D20P-7A, D20PG-7A, D21PG -7A - Serial number 76441, 62001 AND UP - Operation & Maintenance Manual

D20PL-7, D20PLL-7, D20AG-7, D20P-7A, D20PG -7A, D21A-7, D21AG-7, D21PG -7A, D21S-7, D21QG -7, D21A-7A - Serial number 62001 AND UP, 75001 AND UP, 61001 AND UP - Shop Manual

D20S-5, D20Q-5, D21S-5, D21Q-5 - Serial number 45001 AND UP - Shop Manual

D20S-5, D20Q-5 - Serial number 45001 AND UP, 45368 AND UP - ENGINE-4D94-2-0peration & Maintenance Manual

D20S-6, D20Q-6, D21S-6, D21Q-6, D21S-6A - Serial number 60165, 60165, 60178 AND UP, 60184, 60172-0peration & Maintenance Manual

D21A, D21P-8 - Serial number 83001 AND UP - Shop Manual

D21A-8, D21P-8 - Serial number 83001 AND UP - Operation & Maintenance Manual

D21A-8EO, D21P-8EO - Serial number 90001 AND UP - Operation & Maintenance Manual

D21A-8EO, D21P-8EO - Serial number 90001 AND UP - Shop Manual

D21A-8EO, D21P-8EO - Serial number 90219 AND UP - Operation & Maintenance Manual

D31A-16, D31P-16 - Serial number 25001 AND UP - Shop Manual

D31E-18, D31P-18, D31P-18A, D31PL-18, D31PLL-18, D31S-18, D31Q-18, D37E-2, D37P-2 - Serial number 40001 AND UP, 1501 AND UP - Shop Manual

D31E-20, D31P-20, D31PL-20, D31PLL-20, D31P-20A, D37E-5, D37P-5A-Operation & Maintenance Manual

D31E-20, D31P-20, D31PL-20, D31PLL-20, D31P-20A, D37E-5, D37P-5A - Serial number 42199 AND UP, 45001 AND UP, 45785 AND UP, 3235 AND UP, 3153 AND UP - Operation & Maintenance Manual

D31E-20, D31P-20, D31PL-20, D31PLL-20, D31P-20A, D37E-5, D37P-5A - Serial number 42723 AND UP, 47617 AND UP, 47653 AND UP, 47617 AND UP, 3731 AND UP, 3661 AND UP - Operation & Maintenance Manual

D31EX-21, D31PX-21, D37EX-21, D37PX-21, D39EX-21, D39PX-21 - Serial number 50501 AND UP, 5501 AND UP, 1501 AND UP - Operation & Maintenance Manual

D31EX-21, D31PX-21, D37EX-21, D37PX-21, D39EX-21, D39PX-21 - Serial number 50501 AND UP, 5501 AND UP, 1501 AND UP - Shop Manual

D31EX-21, D31PX-21, D37EX-21, D37PX-21-GALEO - Serial number 50001 AND UP, 5001 AND UP - Operation & Maintenance Manual

D31EX-21, D31PX-21, D37EX-21, D37PX-21 - Serial number 50001 AND UP, 5001 AND UP - Shop Manual

D31EX-21, D31PX-21, D37EX-21, D37PX-21 - Serial number 50098 AND UP, 50182AND UP, 5105 AND UP, 5091 AND UP - Operation & Maintenance Manual

D31EX-22, D31PX-22, D37EX-22, D37PX-22 - Serial number 60001 AND UP - ECOT3-0peration & Maintenance Manual

D31EX-22, D31PX-22, D37EX-22, D37PX-22 - Serial number 60001 AND UP - ECOT3-Shop Manual

D31EX-22, D31PX-22, D37EX-22, D37PX-22 - Serial number 60541 AND UP - ECOT3-0peration & Maintenance Manual

D31EX-22, D31PX-22, D37EX-22, D37PX-22 - Serial number 60730 AND UP - ECOT3-0peration & Maintenance Manual

D31S-16, D31Q-16 - Serial number 25001 AND UP - Shop Manual

D37E-2, D37P-2 - Serial number 1501 AND UP - Parts Book

D37EX-23, D37PX-23, D39EX-23, D39PX-23 - Serial number 80001 AND UP, 90001 AND UP - Operation & Maintenance Manual

D37EX-23, D37PX-23, D39EX-23, D39PX-23 - Serial number 80001 AND UP, 90001 AND UP - Shop Manual

D37EX-24, D37PX-24, D39EX-24, D39PX-24 - Serial number 85001 AND UP, 95001 AND UP - Operation & Maintenance Manual

D37EX-24, D37PX-24, D39EX-24, D39PX-24 - Serial number 85001 AND UP, 95001 AND UP - Shop Manual

D37EXi-23, D37PXi-23, D39EXi-23, D39PXi -23 - Serial number 80179 AND UP, 90404 AND UP - Operation & Maintenance Manual

D37EXi-23, D37PXi-23, D39EXi-23, D39PXi-23 - Serial number 80179 AND UP, 90404 AND UP - Shop Manual

D37EXi-24, D37PXi-24, D39Exi-24, D39PXi-24 - Serial number 85001 AND UP, 95001 AND UP - Operation & Maintenance Manual

D37EXi-24, D37PXi-24, D39EXi-24, D39PXi-24 - Serial number 85001 AND UP, 95001 AND UP - Shop Manual

D37EXi-24, D37PXi-24, D39EXi-24, D39PXi-24 - Serial number 85001 AND UP, 95497 AND UP - Operation & Maintenance Manual

D39EX-21, D39PX-21-GALEO - Serial number 1201 AND UP, 1209 AND UP - Operation & Maintenance Manual

D39EX-21, D39PX-21 - Serial number 1001 AND UP - Operation & Maintenance Manual

D39EX-21, D39PX-21 - Serial number 1001 AND UP - Shop Manual

D39EX-22, D39PX-22 - Serial number 3001 AND UP - ECOT3-0peration & Maintenance Manual

D39EX-22, D39PX-22 - Serial number 3001 AND UP - ECOT3-Shop Manual

D39EX-22, D39PX-22 - Serial number 3440 AND UP - ECOT3-0peration & Maintenance Manual

D41E, D41P-6 - Serial number B30001 AND UP - Operation & Maintenance Manual

D41E, D41P-6 - Serial number B35001 AND UP - Operation & Maintenance Manual

D41E-6, D41P-6, D41E-6, D41P-6 - Serial number B20001-B40000, 50001 AND UP - Shop Manual

D41E-6, D41P-6 - Serial number B20001 AND UP - Operation & Maintenance Manual

D41E-6, D41P-6 - Serial number B20501 AND UP - Operation & Maintenance Manual

D41E-6, D41P-6 - Serial number B40001 AND UP - Operation & Maintenance Manual

D41E-6, D41P-6 - Serial number B40001 AND UP - Shop Manual

D41E-6, D41P-6 - Serial number B40694 AND UP, B40688 AND UP - Operation & Maintenance Manual

D41E-6, D41P-6 - Serial number B40865 AND UP - Operation & Maintenance Manual

D51EX-22, D51PX-22 - Serial number B10001 AND UP - ENGINE-6D107E-1-0peration & Maintenance Manual

D51EX-22, D51PX-22 - Serial number B10001 AND UP - ENGINE-6D107E-1-Shop Manual

D51EX-24, D51EXi-24, D51PX-24, D51PXi-24 - Serial number 10001 AND UP - Field Assembly Instruction

D51EX-24, D51PX-24 - Serial number 10001 AND UP - Operation & Maintenance Manual

D51EX-24, D51PX-24 - Serial number 10001 AND UP - Shop Manual

D51EX-24, D51PX-24 - Serial number B20001 AND UP - ENGINE-4D107E-3-0peration & Maintenance Manual

D51EX-24, D51PX-24 - Serial number B20001 AND UP - ENGINE-4D107E-3-Shop Manual

D51EXi-22, D51PXi-22 - Serial number B13500 AND UP - ECOT3-Shop Manual"

D51EXi-22, D51PXi-22 - Serial number B13500 AND UP - ENGINE 6D107E-1-0peration & Maintenance Manual

D51EXi-24, D51PXi-24 - Serial number 10001 AND UP - Operation & Maintenance Manual"

D51EXi-24, D51PXi-24 - Serial number 10001 AND UP - Shop Manual"

D51EXi-24, D51PXi-24 - Serial number B20001 AND UP - ENGINE 4D107E-3-0peration & Maintenance Manual

D57S-1 - Serial number 6501 AND UP - Shop Manual

D57S-1 - Serial number 6501 AND UP - Operation & Maintenance Manual

D57S-1 - Serial number 9001 AND UP - Operation & Maintenance Manual

D57S-1 - Serial number 20001 AND UP - Operation & Maintenance Manual

D60A-6, D60P-6, D60Pl-6, D65A-6, D65P-6 - Serial number 31001 AND UP, 32001 AND UP, 30001 AND UP, 32001 AND UP, 31001 AND UP - Shop Manual

D60A-8, D60E-8, D60P-8, D60Pl-8, D65A-8, D65E-8, D65P-8, D65E-8, D65P-8A - Serial number 45-001 AND UP - ENGINE-6D 125-1-Shop Manual

D61EX-12, D61EX-12, D61PX-12, D61PX-12 - Serial number 1001 AND UP, 81001 AND UP, 1001 AND UP, 81001 AND UP - Shop Manual

D61EX-12, D61PX-12 - Serial number 1001 AND UP - Operation & Maintenance Manual

D61EX-12, D61PX-12 - Serial number 1106 AND UP, 1112 AND UP - Operation & Maintenance Manual

D61EX-12, D61PX-12 - Serial number B1501 AND UP - Operation & Maintenance Manual

D61EX-12, D61PX-12 - Serial number B3001 AND UP - Operation & Maintenance Manual

D61EX-15, D61PX-15-GALEO - Serial number B40001 AND UP - Operation & Maintenance Manual

D61EX-15-D61PX-15 - Serial number B40001 AND UP - Shop Manual

D61EX-15EO, D61PX-15EO - Serial number B45001 AND UP - ECOT3-Shop Manual

D61EX-15EO, D61PX-15EO - Serial number B45001 AND UP - Operation & Maintenance Manual

D61EX-15EO, D61PX-15EO - Serial number B46105 AND UP - ENGINE-6D107E-1-0peration & Maintenance Manual

D61EX-23, D61PX-I3 - Serial number 30001 AND UP - Operation & Maintenance Manual

D61EX-23, D61PX-23 - Serial number 30001 AND UP - Shop Manual

D61EX-24, D61PX-24, D61EXi-24, D61PXi-24 - Serial number B60001 AND UP - ENGINE-6D107E-3 SERIES-Operation & Maintenance Manual

D61EX-24, D61PX-24 - Serial number 40001 AND UP - Operation & Maintenance Manual

D61EX-24, D61PX-24 - Serial number 40001 AND UP - Shop Manual

D61EX-24, D61PX-24 - Serial number B60001 AND UP - Shop Manual

D61EXi-23, D61PXi-23 - Serial number 30324 AND UP - Operation & Maintenance Manual

D61EXi-23, D61PXi-23 - Serial number 30324 AND UP - Shop Manual

D61EXi-24, D61PXi-24 - Serial number 40001 AND UP - Shop Manual

D61EXi-24, D61PXi-24 - Serial number B60001 AND UP - ENGINE-6D107E-3-Shop Manual

D61EZi-24, D61PXi-24 - Serial number 40001 AND UP - Operation & Maintenance Manual

D65-17-WASTE HANDLER DOZER-Product Manual

D65A-8, D65E-8, D65P-8 - Serial number 45001 AND UP - Operation & Maintenance Manual

D65E-12, D65P-12, D65EX-12, D65PX-12 - Serial number 60001 AND UP - Operation & Maintenance Manual

D65E-12, D65P-12, D65EX-12, D65PX-12 - Serial number 60001 AND UP - Shop Manual

D65E-12, D65P-12 - Serial number 60948, 60891 AND UP, J10001-0peration & Maintenance Manual

D65E-12, D65P-12 - Serial number 61441 AND UP, 61365 AND UP - Operation & Maintenance Manual

D65E-12, D65P-12 - Serial number 65001 AND UP - Operation & Maintenance Manual

D65EX-12, D65PX-12 - Serial number 60942 AND UP, 60915 AND UP - Operation & Maintenance Manual

D65EX-12, D65PX-12 - Serial number 61446 AND UP, 61369 AND UP - Operation & Maintenance Manual

D65EX-12, D65P X-12 - Serial number 62959 AND UP, 62771 AND UP - Operation & Maintenance Manual

D65EX-12, D65P X-12 - Serial number 63403 AND UP, 63304 AND UP - Operation & Maintenance Manual

D65EX-12, D65P X-12 - Serial number 65001 AND UP - Operation & Maintenance Manual

D65EX-12, D6S5 X-12 - Serial number 65209 AND UP, 65275 AND UP - Shop Manual

D65EX-12 - Serial number 62745 AND UP - Field Assembly Manual

D6SEX-15, D65PX-15, D65WX-15 - Serial number 67001 AND UP - Operation & Maintenance Manual

D65EX-15, D65PX-15, D65WX-15 - Serial number 67001 AND UP - Shop Manual

D65EX-15, D65PX-15, D65WX-15 - Serial number 67668 AND UP, 67589 AND UP, 67001 AND UP - Operation & Maintenance Manual

D65EX-15EO, D65PX-15EO, D65WX-15EO - Serial number 69001 AND UP - ECOT3-0peration & Maintenance Manual

D65EX-15EO, D65PX-15EO, D65WX-15EO - Serial number 69001 AND UP - ECOT3-Shop Manual

D65EX-15EO, D65PX-15EO, D65WX-15EO - Serial number 71069 AND UP, 71069 AND UP, 69105 AND UP - ECOT3-0peration & Maintenance Manual

D65EX-15EO, D65PX-15EO, D65WX-15EO - Serial number 71676 AND UP, 71676 AND UP, 69124 AND UP - ECOT3-0peration & Maintenance Manual

D65EX-16, D65PX-16, D65WX-16 - Serial number 80001 AND UP - ECOT3-0peration & Maintenance Manual

D65EX-16, D65PX-16, D65WX-16 - Serial number 80001 AND UP - ECOT3-Shop Manual

D65EX-16, D65PX-16, D65WX-16 - Serial number 80012 AND UP - ECOT3-0peration & Maintenance Manual

D65EX-16, D65PX-16, D65WX-16 - Serial number 80159 AND UP - ECOT3-0peration & Maintenance Manual

D65EX-17, D65PX-17, D65WX-17 - Serial number 1001 AND UP - Operation & Maintenance Manual

D65EX-17, D65PX-17, D65WX-17 - Serial number 1001 AND UP - Shop Manual

D65EX-18, D65PX-18, D65WX-18 - Serial number 90001 AND UP - Operation & Maintenance Manual

D65EX-18, D65PX-18, D65WX-18 - Serial number 90001 AND UP -Shop Manual

D65EX-18, D65PX-18, D65WX-18 - Serial number 90166 AND UP - Operation & Maintenance Manual

D65EXi-18, D65PXi-18 - Serial number 90023 AND UP - Operation & Maintenance Manual

D65EXi-18, D65PXi-18 - Serial number 900l3 AND UP - Shop Manual

D65WX-15EO-GALEO-POWER ANGLE POWER TILT DOZER - Serial number 69001 AND UP - Shop Manual

D66S-1 - Serial number 1001 AND UP - Shop Manual

D75S-2 - Serial number 1004 AND UP - Shop Manual

D75S-5 - Serial number 15001 AND UP - Operation & Maintenance Manual

D75S-5 - Serial number 15001 AND UP - Shop Manual

D75S-5 - Serial number 16538 AND UP - Operation & Maintenance Manual

D75S-S - Serial number 16591 AND UP - Operation & Maintenance Manual

D85A, E, P-21 - Serial number 35001 AND UP, 3001 AND UP - Shop Manual

D85A-21, D85E-21, D85P-21 - Serial number 35001 AND UP, 35001 AND UP, 3001 AND UP - Operation & Maintenance Manual

D85A-21, D85E-21, D85P-21 - Serial number 35001 AND UP, 35001 AND UP, 3001 AND UP - Shop Manual

D8SEX-15, D85PX-15-GALEO - Serial number 10001 AND UP, 1001 AND UP - Operation & Maintenance Manual

D85EX-15, D85PX-15 - Serial number 10001 AND UP, 1001 AND UP - Shop Manual

D85EX-15, D85PX-1S - Serial number 10250 AND UP, 1109 AND UP - Operation & Maintenance Manual

D85EX-15EO, D85PX-15EO - Serial number 11001 AND UP, 1201 AND UP - ECOT3-0peration & Maintenance Manual

D85EX-15EO, D85PX-15EO - Serial number 11001 AND UP, 1201 AND UP - ECOT3-Shop Manual

D85EX-15EO, D85PX-15EO - Serial number 11474 AND UP - ECOT3-0peration & Maintenance Manual

D85EX-15EO, D85PX-15EO - Serial number 11601 AND UP - ECOT3-0peration & Maintenance Manual

D85EX-18, D85PX-18 - Serial number 22001 AND UP - Operation & Maintenance Manual

D85EX-18, D85PX-18 - Serial number 22001 AND UP - Shop Manual

D85EX-18, D85PX-18 - Serial number 22061 AND UP - Operation & Maintenance Manual

D85EXi-18, D85PXi-18 - Serial number 22083 AND UP - Field Assembly Instruction

D85EXi-18, D85PXi-18 - Serial number 22083 AND UP - Operation & Maintenance Manual

D85EXi-18, D85PXi-18 - Serial number 22083 AND UP - Shop Manual

D155-7-WASTE HANDLER DOZER-Product Manual

D155A-5 - Serial number 65139 AND UP - Operation & Maintenance Manual

D155A-6 - Serial number 85001 AND UP - Field Assembly Instruction

D155A-6 - Serial number 85001 AND UP - Shop Manual

D155A-6 - Serial number 85071 AND UP - Operation & Maintenance Manual

D155AX-3-SUPER DOZER - Serial number 60001 AND UP - Shop Manual

D155AX-3-SUPER - Serial number 60001 AND UP - Operation & Maintenance Manual

D155AX-3-SUPER - Serial number 60280 AND UP - Operation & Maintenance Manual

D155AX-5-GALEO - Serial number 76001 AND UP - Operation & Maintenance Manual

D155AX-5-GALEO - Serial number 76243 AND UP - Operation & Maintenance Manual

D155AX-5 - Serial number 70001 AND UP - Operation & Maintenance Manual

D155AX-5 - Serial number 70001 AND UP - Shop Manual

D155AX-5 - Serial number 75001 AND UP - Operation & Maintenance Manual

D155AX-5 - Serial number 76001 AND UP - Field Assembly Manual

D155AX-5 - Serial number 76001 AND UP - Shop Manual

D155AX-6 - Serial number 80001 AND UP - ECOT3-Field Assembly Instruction

D155AX-6 - Serial number 80001 AND UP - ECOT3-0peration & Maintenance Manual

D155AX-6 - Serial number 80001 AND UP - ECOT3-Shop Manual

D155AX-6 - Serial number 80807-ECOT3-0peration & Maintenance Manual

D155AX-6 - Serial number 81017 AND UP - ECOT3-0peration & Maintenance Manual

D155AX-6 - Serial number 81077 AND UP - ECOT3-0peration & Maintenance Manual

D155AX-7 - Serial number 90001 AND UP - Field Assembly Instruction

D155AX-7 - Serial number 90001 AND UP - Operation & Maintenance Manual

D155AX-7 - Serial number 90001 AND UP - Shop Manual

D155AX-8 - Serial number 100001 AND UP - Field Assembly Instruction

D155AX-8 - Serial number 100001 AND UP - Operation & Maintenance Manual

D155AX-8 - Serial number 100001 AND UP - Shop Manual

D155AX-8 - Serial number 100070 AND UP - Operation & Maintenance Manual

D155AX-8 - Serial number 100099 AND UP - Operation & Maintenance Manual

D155AXi-8 - Serial number 100040 AND UP - Field Assembly Instruction

D155AXi-8 - Serial number 100040 AND UP - Operation & Maintenance Manual

D155AXi-8 - Serial number 100040 AND UP - Shop Manual

D155C-1 - Serial number 31586AND UP - Shop Manual

D275A-2 - Serial number 10001 AND UP - Shop Manual

D275A-2 - Serial number 10001 AND UP - Operation & Maintenance Manual

D275A-2 - Serial number 10127 AND UP - Operation & Maintenance Manual

D275A-5, D275AX-5 - Serial number 25001 AND UP, 20001 AND UP - Field Assembly Instruction

D275A-5-GALEO - Serial number 25178 AND UP - Operation & Maintenance Manual

D275A-5R - Serial number 35001 AND UP - Shop Manual

D275A-5 - Serial number 25001 AND UP - Shop Manual

D275AX-5EO-GALEO - Serial number 30001 AND UP - ECOT3-0peration & Maintenance Manual

D275AX-5EO - Serial number 30001 AND UP - Field Assembly Instruction

D275AX-5EO - Serial number 30132 AND UP - ECOT3-0peration & Maintenance Manual

D275AX-5EO - Serial number 30209 AND UP - ECOT3-0peration & Maintenance Manual

D275AX-5EO - Serial number 30217 AND UP - ECOT3-0peration & Maintenance Manual

D275AX-5EO - Serial number 40001 AND UP - ECOT3-Field Assembly Instruction

D275AX-5EO - Serial number 40001 AND UP - ECOT3-0peration & Maintenance Manual

D275AX-5EO - Serial number 30001 AND UP - Shop Manual

D275AX-5-GALEO - Serial number 20001 AND UP - Operation & Maintenance Manual

D275AX-5-GALEO - Serial number 20164 AND UP - Operation & Maintenance Manual (2)

D275AX-5-GALEO - Serial number 20164 AND UP - Operation & Maintenance Manual

D275AX-5 - Serial number 20001 AND UP - LANDFILL SPECIFICATION-Shop Manual

D275AX-5 - Serial number 20001 AND UP - Shop Manual

D355A-5 - Serial number 12622AND UP - Shop Manual

D355C-3-PIPELAYER - Serial number 14413AND UP - Operation Maintenance Manual

D375A-2 - Serial number 16001 AND UP - Shop Manual

D375A-2 - Serial number 16305 AND UP - Operation & Maintenance Manual

D375A-3 - Serial number 17001 AND UP - Operation & Maintenance Manual

D375A-3 - Serial number 17001 AND UP - Shop Manual

D375A-3 - Serial number 17501 AND UP - Operation & Maintenance Manual

D375A-3 - Serial number 17501 AND UP - Shop Manual

D375A-3 - Serial number 17736 AND UP - Operation & Maintenance Manual

D375A-3 - Serial number 17736AND UP - Shop Manual

D375A-5EO-GALEO - Serial number 50001 AND UP - Operation & Maintenance Manual

D375A-5EO - Serial number 50001 AND UP - ECOT3-Field Assembly Instruction

D375A-5EO - Serial number 50001 AND UP - Shop Manual

D375A-5EO - Serial number 50065AND UP - ECOT3-0peration & Maintenance Manual (2)

D375A-5EO - Serial number 50065AND UP - ECOT3-0peration & Maintenance Manual

D375A-5EO - Serial number 50091 AND UP - ECOT3-0peration & Maintenance Manual

D375A-5-GALEO - Serial number 18001 AND UP - Field Assembly Manual

D375A-5-RADIO CONTROL SPECIAL SMALL ELECTRIC POWER SPECIFICATION-Operation & Maintenance Manual

D375A-5-RADIO -CONTROL SPECIFICATION - Serial number 18020, 18040-Shop Manual

D375A-5 - Serial number 18001 AND UP - Operation & Maintenance Manual

D375A-5 - Serial number 18001 AND UP - Shop Manual

D375A-5 - Serial number 18052 AND UP - Operation & Maintenance Manual

D375A-5 - Serial number 18200 AND UP - Operation & Maintenance Manual

D375A-5 - Serial number 18200 AND UP - Shop Manual

D375A-5-VHMS SPECIFICATION - Serial number 18052 AND UP - Shop Manual

D375A-6R - Serial number 65001 AND UP - Operation & Maintenance Manual

D375A-6R - Serial number 65001 AND UP - Shop Manual

D375A-6 - Serial number 60001 AND UP - ECOT3-Field Assembly Instruction

D375A-6 - Serial number 60001 AND UP - ECOT3-0peration & Maintenance Manual

D375A-6 - Serial number 60001 AND UP - ECOT3-Shop Manual (2)

D375A-6 - Serial number 60001 AND UP - ECOT3-Shop Manual

D375A-6 - Serial number 60018 AND UP - ECOT3-0peration & Maintenance Manual (2)

D375A-6 - Serial number 60018 AND UP - ECOT3-0peration & Maintenance Manual

D375A-6 - Serial number 60001 AND UP - ECOT3-Field Assembly Instruction

D375A-8-SN '80001 AND UP - Field Assembly Instruction

D375A-8 - Serial number 80001 AND UP - Operation & Maintenance Manual

D375A-8 - Serial number 80001 AND UP - Shop Manual

D475A-2 - Serial number 10201 AND UP - Operation & Maintenance Manual

D475A-2 - Serial number 10201 AND UP - Shop Manual

D475A-2 - Serial number 10282 AND UP - Operation & Maintenance Manual

D475A-2 - Serial number 10365AND UP - Operation & Maintenance Manual

D475A-3-PALM CONTROL SPECIFICATION - Serial number 10695 AND UP - Shop Manual

D475A-3 - Serial number 10601 AND UP - Field Assembly Manual

D475A-3 - Serial number 10601 AND UP - Operation & Maintenance Manual

D475A-3 - Serial number 10601 AND UP - Shop Manual

D475A-3 - Serial number 10685 AND UP - Operation & Maintenance Manual

D475A-3 - Serial number10695 AND UP - Operation & Maintenance Manual

D475A-3-SUPER DOZER - Serial number 10685 AND UP - Operation & Maintenance Manual

D475A-5EO, D475ASD-5EO - Serial number 30001 AND UP - Field Assembly Instruction

D475A-5EO, D475ASD-5EO - Serial number 30001 AND UP - Shop Manual

D475A-5EO - Serial number 30001 AND UP - Operation & Maintenance Manual

D475A-5EO - Serial number 30071 AND UP - Operation & Maintenance Manual

D475A-5EO - Serial number 30126 AND UP - Operation & Maintenance Manual

D475A-5EO - Serial number 30134 AND UP - Operation & Maintenance Manual (2)

D475A-5EO - Serial number 30134 AND UP - Operation & Maintenance Manual

D475A-5 - Serial number 20001 AND UP - Field Assembly Instruction

D475A-5 - Serial number 20001 AND UP - Operation & Maintenance Manual (2)

D475A-5 - Serial number 20001 AND UP - Operation & Maintenance Manual (3)

D475A-5 - Serial number 20001 AND UP - Operation & Maintenance Manual

D475A-5 - Serial number 20001 AND UP - Shop Manual

D475ASD-5EO - Serial number 30001 AND UP - Operation & Maintenance Manual

D475ASD-5EO - Serial number 30071 AND UP - Operation & Maintenance Manual

D575A-2 - Serial number 10002 AND UP - Operation & Maintenance Manual

D575A-2 - Serial number 10035 AND UP - Operation & Maintenance Manual

D575A-2 - Serial number 10035 AND UP - Shop Manual

D575A-2-SUPER DOZER - Serial number 10012AND UP - Field Assembly Instruction

D575A-2-SUPER DOZER - Serial number 10012AND UP - Operation & Maintenance Manual

D575A-2-SUPER DOZER - Serial number 10012AND UP - Shop Manual

D575A-2-SUPER DOZER - Serial number 10042 AND UP - Operation & Maintenance Manual

D575A-3 - Serial number 10101 AND UP - Operation & Maintenance Manual

D575A-3-SUPER DOZER - Serial number 10101 AND UP - Field Assembly Manual

D575A-3-SUPER DOZER - Serial number 10101 AND UP - Shop Manual

TD-15H - Serial number 32501 AND UP - Operators Manual

TD-20H - Serial number 5201 AND UP - Operators Manual

TD-25H - Serial number 73001 AND UP - Operators Manual

TD-40C - Serial number 1501 AND UP - Operators Manual

TD-40C - Serial number 1501 AND UP - Service Manual

WD600-1H - Serial number 10169AND UP - Operation & Maintenance Manual

WD600-1H - Serial number 10169AND UP - Shop Manual

WD600-1 - Serial number 10001 AND UP - Operation & Maintenance Manual

WD600-1 - Serial number 10001 AND UP - Shop Manual

WD600-3 - Serial number 50001 AND UP - Operation & Maintenance Manual

WD600-3 - Serial number 50001 AND UP - Shop Manual

WD600-6 - Serial number 55001 AND UP - ECOT3-Field Assembly Instruction

WD600-6 - Serial number 55001 AND UP - ECOT3-0peration & Maintenance Manual

WD600-6 - Serial number 55001 AND UP - ECOT3-Shop Manual

WD600-6 - Serial number 55012 AND UP - ECOT3-0peration & Maintenance Manual

WD900-3 - Serial number 50001 AND UP - Field Assembly Instruction

WD900-3 - Serial number 50001 AND UP - Operation & Maintenance Manual


WD900-3 - Serial number 50001 AND UP - Shop Manual

Shop Manual – instrukcje napraw – DTR


Instrukcje napraw - schematy instalacji

DISASSEMBLING


STEP 11
Remove the brake shaft.



STEP 12
Remove the toothed ring.





STEP 13
Remove the 1st stage sun gear.




WORK EQUIPMENT - ONE PIECE BOOM

PW150ES-6K







A – A




D – D



H – H




E – E




J – J




B – B




F – F




K – K



C – C




G – G



L – L

Circuit diagram related to engine preheater/starting motor/charging system



N·m **90 ± 3 Nm {9.2 ± 0.3 kgm}**


2] .

N·m Recheck the torque:
90 ± 3 Nm {9.2 ± 0.3 kgm}


3]

N·m **90° ± 5°** (Tighten with an angle tightening tool.)


a Tool **A6**: wrench is adopted for angle tightening. (Refer to the tool list.) (Refer to the tool list.)



- When an angle tightening tool is not used:
  Put marks on the cylinder head and bolts with a felt-tip pen, and then tighten the bolts an additional **90° ± 5°**.



3. Install push rods (57).
4. Install rocker arm support (58).




5. Fuel injector assembly
   - Check that there is no damage or dust on the fuel injector sleeve.

5.1. Install O-ring (63) and gasket (64) to fuel injector (62).

5.2. Coat O-ring (63) and the head side of fuel injector (62) with engine oil (EO15W-40).


O-ring (63) and the head side of fuel injector (62): **engine oil (EO15W-40)**

5.3. Install holder (65) to fuel injector (62) with concavity and convexity (A) fitted together.



DISASSEMBLY OF PRESSURE COMPENSATION VALVE ASSEMBLY

Pressure compensation valves
A: For bucket CURL/DUMP, boom Lower arm IN, stabiliser
C: For swing LEFT/RIGHT
D: For arm OUT, boom RAISE
B: For travel



- **Disassembly of pressure compensation valves A,C,D**
- The structure of the parts for pressure compensation valves A, C en D is the same, but the part number for the assembly marked ★ is different, so be careful when assembling.

1. Remove piston (2) and spring (3) from sleeve (1).
2. Remove plug (4) and ball (5) form piston (2).
3. Remove seals (6) and (7) from piston (2).
4. Remove O-ring (8) from sleeve (1), then remove seals (9) and (10), and O-ring (11).

* After disassembling, if there is any abnormality in sleeve (1), piston (2), plug (4), ball (5), or seals (6) and (7), replace the whole pressure compensation valve assembly.

- **Disassembly of pressure compensation valve B**


1. Remove piston (13) and spring (14) from sleeve (12).
2. Remove seals (15) and (16) from piston (13), then remove O-ring (17), seals (18) and (19), and O-ring (20) from sleeve (12).


* After disassembling, if there is any abnormality in sleeve (12), piston (13), or seals (15) and (16), replace the whole pressure compensation valve assembly.


IDENTIFICATION OF PRESSURE COMPENSATION VALVE ASSEMBLY


Valves are identified by markings on the valve assembly.

FRONT TRAVEL MOTOR (20 Km/h TRAVEL SPEED SPEC.)









HYDRAULIC SCHEMATIC


SPECIFICATIONS


Type: Variable displacement piston motor


Theoretical delivery:	Min. 32 cc/rev
	Max. 80 cc/rev
Hi-Lo switching-pressure:	2.94 MPa (30 kg/cm²)
Rated speed:	4968 rpm. (Max)


a. Motor inlet (A)
b. Motor outlet (B)
c. Override pressure port (X)
d. Drain port (U)
e. Drain port (T)
f. Pressure test port (MB)
g. Pressure test port (MA)
h. Pressure test port (M1)
i. Pressure test port (G)

SWING MOTOR










a. Port **G** (to control valve TSW port)
b. Port **MB** (from control valve)
c. Port **MA** (from control valve)
d. Port **T** (to tank)
e. Port **L** (plugged)

SPECIFICATIONS

Type	F12-060-MF-CV-C-509
Theoretical delivery	59.8 cc/rev
Safety valve set pressure	31.36 MPa (320 kg/cm^2)
Rated speed	2250 rpm



Powyższe zdjęcia pochodzą z losowych instrukcji napraw do maszyn budowlanych marki Komatsu.

Format PDF

Język angielski

Kontakt tel: 696 915 311

motodiagnostyka2010@gmail.com

Szukasz instrukcji napraw, schematów lub DTR do innego modelu? Zadzwoń lub napisz do nas.